



BG-UM44-150L-KIT

Control4 Driver User Manual

4x4 HDMI / HDBaseT (150m, PoC) Matrix Kit with Mirrored HDMI + HDBaseT Outputs

Table of Contents

Statement

Safety Precaution

Introduction

Installation

Properties

Actions

Programming Commands

Events & Variables

Connections (Bindings)

ASCII Command Reference

Tech Support

Warranty

Mission Statement

Copyright

Statement

Please read these instructions carefully before connecting, operating, or configuring this product. Please save this manual for future reference.

Safety Precaution

- To prevent damaging this product, avoid heavy pressure, strong vibration, or immersion during transportation, storage, and installation.
- The housing of this product is made of organic materials. Do not expose to any liquid, gas, or solids which may corrode the shell.
- Do not expose the product to rain or moisture.
- To prevent the risk of electric shock, do not open the case. Installation and maintenance should only be carried out by qualified technicians.
- Do not use the product beyond the specified temperature, humidity, or power supply specifications.
- This product does not contain parts that can be maintained or repaired by users. Damage caused by dismantling the product without authorization from BZBGear is not covered under the warranty policy.
- Installation and use of this product must strictly comply with local electrical safety standards.

Introduction

This guide covers the Control4 driver for the BZBGear BG-UM44-150L-KIT 4x4 HDMI / HDBaseT matrix kit. The driver is built on the Control4 DriverWorks SDK using the AV Switch proxy and controls the matrix over TCP/IP or RS-232.

It exposes the matrix's 4 HDMI inputs and 4 outputs, where each output is mirrored to an HDMI connector and an HDBaseT connector (150m with PoC). Routing is per output and carries video and audio together (there is no separate audio matrix on this model). The driver adds per-connector output scaler and stream on/off, per-input EDID, matrix presets, HDMI-CEC to sources and displays, and front-panel settings, with two-way routing and hot-plug feedback.

Installation

Copy the driver (.c4z) into your Control4 driver folder, then in Composer Pro use Driver -> Add or Update Driver... and add it to your project. On the Connections page, bind the sources and displays as described under Connections (Bindings).

To control the device over the network, set the following on the Properties page:

Setting	Value
Connection Type	Network (TCP) or RS-232, selected on the Properties page.
IP Address	The IP address of the matrix (front-panel LCD, or via 'r ipconfig!'). Auto-filled when discovered over SDDP.
TCP Port	8000 (factory default)

To use the RS-232 connection instead, set Connection Type to RS-232 and use the following serial settings:

- 115200 baud, 8 data bits, no parity, 1 stop bit

If the device supports SDDP, it is discovered automatically and the IP Address is filled in for you.

Properties

The driver exposes the following properties on the Composer Properties page. Read-only properties reflect live status reported by the device.

Property	Access	Description
Connection Type	Editable	How the driver talks to the matrix. Network uses the IP Address and TCP Port below; RS-232 uses the serial binding on the Connections page at 115200 8N1.
IP Address	Editable	IP address or hostname of the BG-UM44-150L-KIT. Populated automatically when the matrix is discovered over SDDP. Otherwise read it from the front panel LCD or send 'r ipconfig!'.
SDDP Auto-Configure IP	Editable	When Yes, the driver follows the IP address reported by SDDP discovery, so the matrix keeps working after a DHCP lease change. Set to No to pin the IP Address field manually.
Discovered By	Read-only	How the matrix was located: SDDP discovery or manual configuration.
TCP Port	Editable	TCP control port of the matrix. Factory default is 8000.
Connection Status	Read-only	Current state of the IP connection to the matrix.
Model	Read-only	Model reported by the matrix.
Firmware Version	Read-only	MCU firmware version reported by the matrix.
Power State	Read-only	Power state reported by the matrix.
Last Device Error	Read-only	Most recent error string returned by the matrix, e.g. a rejected command.
Poll Interval	Editable	Seconds between status polls, which keep Control4 in sync with front panel and web GUI changes. Set to 0 to disable polling.
Front Panel Lock	Editable	Lock or unlock the matrix front panel buttons.
Buzzer	Editable	Enable or disable the front panel buzzer.
Debug Mode	Editable	Diagnostic output. Automatically returns to Off after one hour.
Driver Version	Read-only	Driver version.

Actions

The following actions are available on the Composer Actions tab.

Action	Description
Reconnect	Tear down and re-establish the connection to the device.
Query Status	Refresh all state from the device.
Print Routing Table	Print the current routing to the Lua output window.
Reboot Device	Reboot the device.
Factory Reset Device (erases matrix configuration)	Reset the matrix to factory defaults (erases configuration, including network settings).

Programming Commands

The following device-specific commands are available in the Composer Programming tab. Parameters are chosen from drop-down lists unless noted.

Command	Parameters	Description
Route Video	Output, Input	Route HDMI input PARAM2 to output PARAM1 (HDMI + HDBaseT, audio follows)
Set Output Stream	Output, Connector, State	Enable/disable the stream on output PARAM1 connector PARAM2
Set Output Scaler	Output, Connector, Mode	Set output PARAM1 connector PARAM2 scaler mode to PARAM3
Set Input EDID	Input, EDID	Set HDMI input PARAM1 EDID to PARAM2
Set Power	State	Turn the matrix PARAM1
Set Panel Lock	State	Set the front panel lock PARAM1
Set Buzzer	State	Set the buzzer PARAM1
Set LCD Timeout	Timeout	Set the LCD backlight timeout to PARAM1
Recall Preset	Preset	Recall matrix preset PARAM1
Save Preset	Preset	Save the current routing to matrix preset PARAM1
Clear Preset	Preset	Clear matrix preset PARAM1
CEC Input Command	Input, Command	Send CEC PARAM2 to the source on input PARAM1
CEC Display Command	Output, Connector, Command	Send CEC PARAM3 to the display on output PARAM1 connector PARAM2
Query Status	-	Refresh all state from the matrix
Reboot Device	-	Reboot the matrix
Send Raw Command	Command	Send the raw ASCII command PARAM1 to the matrix (the trailing ! is added if missing)

Events & Variables

Events (available as "when" triggers in Programming):

- Device Online
- Device Offline
- Video Route Changed
- Power State Changed
- Input Connection Changed
- Output Connection Changed

Variables (available for programming and conditionals):

Variable	Type	Description
CONNECTED	Bool	True while the driver is connected to the matrix.
POWER_ON	Bool	True when the matrix is powered on.
MODEL	String	Model reported by the matrix (BG-UM44-150L-KIT).
FIRMWARE	String	MCU APP firmware version.
OUTPUT_01_INPUT ... OUTPUT_04_INPUT	Number	The input currently routed to each output.
INPUT_01_CONNECTED ... INPUT_04_CONNECTED	Bool	Whether a source is detected on each HDMI input.
OUTPUT_01_CONNECTED ... OUTPUT_04_CONNECTED	Bool	Whether a display is detected on either connector of each output.

Connections (Bindings)

On the Composer Connections page, bind the following. Unused bindings are hidden automatically on Control4 OS 3.3.0 and later.

Binding	Type	Description
HDMI In 1 - 4	Video Input	Connect sources (players, PCs, cable boxes) to the matrix inputs.
Output 1 - 4 (HDMI/HDBT)	Video Output	Bind displays. Each output feeds both its HDMI and its HDBaseT (150m) connector with the same routed source.
Room Selection 1 - 4	Room Selection	Optional: let a room drive the matrix output directly.
RS-232	Serial	Optional serial control in place of the network connection.

ASCII Command Reference

The matrix is controlled with ASCII strings terminated by "!". Network: TCP port 8000 (also Telnet 23). Serial: 115200 8N1. Routing feedback is reported as "input X -> output Y". The following summarizes key commands; see the product command list for the full set.

Routing

Command	Description
s in X av out Y!	Route input X to output Y (Y=0 for all)
r av out 0!	Read all routes (returns input X -> output Y)

Per-connector output

Command	Description
s hdmi Y stream Z! / s hdbt Y stream Z!	Stream on/off (Z=0/1) for the HDMI / HDBaseT connector
s hdmi Y scaler Z! / s hdbt Y scaler Z!	Scaler 1 bypass, 2 4K->1080p, 3 auto

EDID / Preset / CEC

Command	Description
s edid in X from Z!	Set input X EDID (Z=1-31, incl. copy from an output)
s save / recall / clear preset Z!	Matrix presets (Z=1-4)
s cec in X ...! / s cec hdmi out Y ...! / s cec hdbt out Y ...!	CEC to a source / HDMI display / HDBaseT display

System

Command	Description
s power 1! / s power 0!	Power on / off
s beep Z! / s lock Z!	Buzzer / front-panel lock (Z=0/1)
s lcd on time Z!	LCD timeout: 0 off, 1 always, 2 15s, 3 30s, 4 60s
s reboot! / s reset!	Reboot / factory reset

Tech Support

For technical support, please contact BZBGear:

- Email: support@bzbgear.com
- Phone: +1(888)499-9906
- Address: 830 National Drive #140, Sacramento, CA 95834, USA

Warranty

BZBGear products are backed by a limited product warranty. For full warranty details, please visit www.bzbgear.com or contact BZBGear support.

Mission Statement

BZBGear is dedicated to providing high-quality, professional-grade AV equipment that delivers exceptional performance and reliability for both commercial and residential applications.

Copyright

All rights reserved. No part of this document may be reproduced without the express written permission of BZBGear. BZBGear reserves the right to change specifications without notice. Control4 and Composer Pro are trademarks of Wirepath Home Systems, LLC (Snap One). HDMI is a trademark of HDMI Licensing LLC.